



Supplemental Instructions for Windload Rated Doors

Step 3: in the residential installation instructions or **Step 5:** in the commercial installation instructions, refer to the engineering drawing for the quantity, size, and location of struts.

Step 9: in the residential installation instructions, long stem 7" rollers will be used in the bottom corner brackets.

Step 10: in the residential installation instructions, residential doors will have 3 jamb brackets per side. Refer to the engineering drawing for the location of jamb brackets.

Step 12: in the residential installation instructions or **Step 13:** in the commercial installation instructions, In addition to the 5/16" X 1 5/8" lag screws used to fasten the track to the jamb, drywall screws need to be installed through the 3/16" hole in the foot of the jamb bracket. Refer to the engineering drawing for a detailed view of the jamb bracket installation.