



## **Supplemental Instructions for Low Headroom Conversion Kit**

In addition too switching to the new track and hardware provided (Top brackets, Bottom Brackets, Horizontals and reattaching EBF's, USA, and spring line) Refer to Supplemental Instructions for low headroom install for instructions on how to install new hardware.

The installer must cut the original vertical track to these specs. The vertical tracks lengths must be as follows for this conversion to work correctly:

2" 12" Radius track – Cut off 4.25" off bottom of vertical track.

2" 15" Radius track – Cut off 6" off bottom of vertical track.

3" track - Cut off 8" off bottom of vertical track.

**NOTE:** It is important that the vertical tracks are cut from the bottom; otherwise the installer will have to drill new mounting holes in the top of the vertical tracks.