

Supplemental Instructions for Low Headroom Conversion Kit

In addition to switching to the new track and hardware provided (Top brackets, Bottom Brackets, Horizontals, reattaching EBF's, USA, and Spring Line). Refer to other Supplemental Instructions for Low Headroom pages for instructions on where and how to install new hardware.

The installer must cut the original vertical track to the specifications below.

Vertical track(s) lengths must measure as follows:

- 2" track w/ 12" Radius - Cut 4.25" off bottom of vertical track.
- 2" track w/ 15" Radius - Cut 6" off bottom of vertical track.
- 3" track - Cut 8" off bottom of vertical track.

Special Note: It is important that the vertical tracks are cut from the bottom; otherwise, the installer will have to drill new mounting holes in the top of the vertical tracks.