



Supplemental Instructions **Windload Rated Doors**

Step 3 in the residential installation instructions or **Step 5** in the commercial, refer to the engineering drawing for the quantity, size, and location of struts.

Step 9 in the residential installation instructions, long stem 7" rollers will be used in the bottom corner brackets.

Step 10 in the residential installation instructions, residential doors will have 3 jamb brackets per side. Refer to the engineering drawing for the location of jamb brackets.